
USB Receipt Printer Setup

Follow the steps below to setup your USB receipt printer¹:

Install Epson Receipt Printer Drivers

1. From the **Tools** drop-down menu select **Options**.
2. Click the **Hardware Setup** tab.
3. Under the **Receipt Printer** section, click the **Configure Receipt Printer** button.
4. Select the **Use Epson USB Printer** option.
5. Click on **Install Driver**.
6. A message box will prompt you asking if you are sure you would like to install the drivers. If you are sure this is an Epson USB printer, then select **Yes**.
7. A message box will now prompt you asking if you would like to install the drivers from the **CD** or the **Internet**.
 - **CD:** If you are installing from the CD, make sure the software by DaySmart Software CD is in the CD/DVD drive and select the **CD** option and click **OK**. A list of drivers for your system will be displayed. Select the option for the printer and operating system that you have and click **OK**.
 - **Internet:** If you do not have the CD and would like to install the drivers from the Internet, select the **Internet** option and click **OK**. This will take you to the web page with a list of drivers. Click on the [Epson Receipt Printer Drivers](#) link. After it finishes downloading, run the driver setup file.
8. The software will perform a silent installation of the Epson drivers. It will ask you to select your printer from a list of supported Epson receipt printers. If you do not know the model, there is typically a silver sticker on the right-hand side of the printer with the model number, i.e. TM-T88IV. The installation may take a few minutes and the computer may automatically restart if necessary.
9. After the setup finishes, connect your Epson receipt printer to the USB port on your computer. Make sure the printer has paper in it and the green light is on with no red error lights.
10. You can test your printer by going back into the **Receipt Printer Setup** screen, see **Steps 1 – 3**.
11. Click the **Print Test Receipt** button to print a test receipt to verify the printer is working correctly.
12. Click **OK**, and then **OK** again to save the settings and return using the software.

¹: Do not connect your Epson receipt printer to the USB port on your computer until instructed to do so. Failure to do this may result in installation complications.